TOSHIBA OWNER MANUAL

Toshiba Home AC Control

Please visit the application store on your device to download and install Toshiba Home AC Control application.

Application
Keyword : Toshiba Home AC Control

Toshiba Home AC Control application support.

iOS : 9.0 or later.

Android : Version 5.0 or later.

About Toshiba Home AC Control.

1. Toshiba Home AC Control can control AC operation by Smartphone or tablet (mobile device) via internet connection.
2. Everywhere control, control software run on Cloud system and mobile device can set and monitor AC operation via internet connection.
3. Everyone can control, 1 Wireless adapter maximum 5 user (use 1 email register).
4. Multi AC system control, 1 user can control 10 AC.
5. Group control.
>   5.1 Can create and control 3 groups of AC.
>   5.2 Can control max 10 AC per group.

Note :
>   1. Adapter can register only 1 email address, if register with new email, current email will be invalid.
>   2.1 e-mail address can use for register 5 devices for control same AC.

Register process.

Open an application and follow register for User registration.

① Tab Register

② Enter e-mail address

③ Select country

④ Enter user name

⑤ Enter password by 6-10 characters, combination of alphabet and number

⑥ Check for term and condition

⑦ Confirm information

⑧ Information will be submitted to e-mail, click link to confirm

Log in to Toshiba Home AC Control application.

① Connect Wireless adapter to AC and turn on power supply.

WIRELESS LED : ON
LINK LED : OFF
POWER LED : ON

Build-in type , Wireless adapter already install with unit.

Type A & B-type , Wireless adapter sale separately.

Wireless LED = **ON**
Link LED = OFF
Power LED = **ON**

Operation LED = **ON**

TOSHIBA
○ SETUP   🛜 LINK   ○ OPERATION
○ RESET   ⏻   ○ ERROR
                              ○ BUS
                              ○ UART

Type C , Wireless interface sale separately.


② Open application and select Log in.

③ Enter user name and password.

④ Log in successful.

Add Wireless adapter for control by Toshiba Home AC Control application.

Wireless adapter Build-in
Active Wireless adapter by remote controller and Auto log in.

Wireless adapter type A
Need to input SSID and Password of Wireless adapter for log in.

Wireless adapter type B
Wireless adapter auto log in.

Wireless adapter type C
Wireless adapter auto log in.

① Select "Add AC (Adapter)" from both display above.

② Select AC (adapter) connection method.

*Note
1. In case of Wi-Fi router change or Email for register change need to re-process for add Wireless adapter again
   (Build in type : Press MODE button at Remote controller 5S for active AP mode).
   (Option-type A,B,C : Press SETUP button 1 time for active AP mode).
2. In case of change Wireless adapter to use with other A/C need to factory reset and re-process for add Wireless adapter again
   (Build in type : Press MODE button at Remote controller 5S and select "rb").
   (Option-type A,B,C : Press and hold SETUP 5s)

Add Wireless adapter for control by Toshiba Home AC Control application

③ AC (adapter) connect

Add AC (Adapter)
Select AC (adapter) connection method
- Wireless Adapter Built-in
- Wireless Adapter Type A
  RB-N101S-G
  RB-N102S-G
  RB-N103S-G
  RB-N104S-G
- Wireless Adapter Type B
  RB-N101S-G
  RB-N103S-G
- Wireless Adapter Type C
  HWS-iWP901GUR-E
- Cancel

Add AC (Adapter)
Select AC (adapter) connection method
- Scan Data Matrix code
- Input SSID and Password
  SSID: AhCdEfGh
  P/W: 1a2b3c4d
- Cancel

Add AC (Adapter)
Data Matrix Scaning process...
If cannot scan please back to input AC (Adapter) SSID and passwords"

Add AC (Adapter)
Please input AC (Adapter) SSID and Password
SSID: Input SSID
Password: Input Password
☐ Show password
Next
Cancel

Add AC (Adapter)
Scan result adapter Data Matrix code
SSID: AbCdEfGh
Password: 1a2b3c4d
Next
Cancel   Scan again

Active Wi-Fi adapter by Remote controller

Add AC (Adapter)
Wireless Adapter Built-in
Please press and hold "MODE" button on remote control for 5 seconds.

MODE
Hold 5 sec.

When the wireless LAN icon on air conditioner starts flashing, the wireless LAN pairing (AP access point) mode has been successfully start.

Next
Cancel

Add AC (Adapter)
Select Wi-Fi Router connection method
- WPS method
- Input SSID and Password

Manual input

Add AC (Adapter)
Please input Wi-Fi home router SSID and Password — Wi-Fi Router Name
SSID: Input SSID
Password: Input Password — Wi-Fi Router Password
Next
Cancel
recommend 1   recommend 2   recommend 3

Q W E R T Y U O I P
A S D F G H J K L
Z X C V B N M
123   space   return

WPS mode

Add AC (Adapter)
Activate WPS mode on Wi-Fi Router (WPS activation method base on router type. Please check router manual)

If you do not support WPS or do not know, please tap "Go to SSID and password"
Next
Go to SSID and password

④ Connect with Home Wi-Fi Router

When connect successfully

Build in type

Wi-Fi LED lamp stop blink.

Home
All AC
Mode Set / Room
Living Room   --/-- °C

⑤ AC add finished

Type A & B

Only POWER LED ON.
WIRELESS LED : OFF
LINK LED : OFF
POWER LED : ON

SETUP   LINK
RESET

Type C

TOSHIBA

Operation LED = ON

○ SETUP   ● OPERATION
○ LINK   ○ ERROR
○ RESET   ○ BUS
             ○ UART

Toshiba Home AC Control application.
Home screen

Weekly schedule

Setting

Menu

Weekly Schedule

Monday
0   6   12   18   24

All AC
1st floor
Living ...m
Bed Room
Kitchen
Bath R...m
Den
2nd floor
Child R... 1
Child R... 2
Guest R. 1

10:48 AM   100%
Settings

User Information   tceuadmin4
Change Password
Time zone   New York
Languages   English (United States)

Child lock   On
Confirmation pop up   Off
Add AC (Adapter)

Version   0.0.33.0
License Agreement

▼ ▲ ▮ 10:48

Home
Settings
Toshiba AC special feature
Google Assistant
Amazon Alexa
Wireless adapter manual
Help
Logout

Add AC

Home

All AC
Mode Set / Room

1st floor (Ams)

Living Room (A... Ⓐ 25 / 28 °C

Dining Room (... ❄ -- / -- °C

Bath Room (A... ❄ -- / -- °C

2nd floor (Ams)

Bed Room (Ams) Ⓐ 25 / 28 °C

Children Room... ☀ -- / -- °C

All AC On/Off

Group AC On/Off

Each AC On/Off

Group name

AC device is offline

Notification ERROR code description (pop up)

Sub menu all AC
· Add Group
· Delete Group
· Operation Setting

Sub menu group
· Select AC
· Change group name
· Group operation Setting

Sub menu AC
· Operation Setting
· Change name
· Delete AC

Setting temperature / Actual room temp

Current operation mode of each AC

Energy
Monitoring

Service
Function

Message

Energy Monitoring

Cost Calculator   0.1 EUR/kWh
Display
Export Data
Clear Data

Service Function

Service

Message

All   News   Promotion

This is Subject of test   6/27/2020
Promotion Message   10:48:10 AM
This is body of test message 2
XXXXXXXXXXXXXXXXXXXXX

This is Subject of test   6/27/2020
Promotion Message   10:48:10 AM
This is body of test message 2
XXXXXXXXXXXXXXXXXXXXX

This is Subject of test   6/27/2020
Promotion Message   10:48:10 AM
This is body of test message 2
XXXXXXXXXXXXXXXXXXXXX

Link to service center (available in some countries)

Mode and Condition setting.

Enter operation mode of All AC

Enter operation mode of Group AC

Enter operation mode of each AC

Mode select for Toshiba Home AC Control application.

Provide for 5 operation modes

Auto	Cool	Dry

Heat	Fan only	Off

Setting in operation mode.

Tab for select AC

Weekly schedule

Mode select

OFF-ON Timer set

Temperature set

Indoor temperature

Outdoor temperature

Fan speed set

Special feature

OFF-ON timer set 0.5-12hrs.

Off Timer	On Timer
Please Select huor	Please Select huor
● 0.5	○ 0.5
○ 1.0	○ 1.0
○ 1.5	● 1.5
○ 2.0	○ 2.0
○ 2.5	○ 2.5
○ 3.0	○ 3.0
○ 3.5	○ 3.5
CANCEL START	CANCEL START

ON timer set from Off mode only

Off mode

Louver configuration (support only specific AC model)

LED wireless adapter and AC ON/OFF control.

Wireless adapter

Adapter version
1.00.02

LED Wireless adapter
LED AC + Adapter

Select On/Off

SETUP   LINK

RESET

SETUP   LINK

RESET

Group operation.
Maximum 3 groups
1 Group maximum = 10 units.

Add group

Add AC in group

Delete AC in group

Weekly schedule set.

Day select Monday - Sunday

Weekly schedule of all AC unit

Weekly schedule of all AC unit

Time select

Weekly schedule set for each unit

Mode select

Select program for active by tick at select box

Weekly schedule cancel.

Weekly schedule
not set

Weekly schedule
set but not active

Weekly schedule
set and active

Energy monitoring

Select Room for Energy monitoring

① Select Energy monitoring

② Energy monitoring display

Set cost calculate and currency

Select Energy monitoring display

Export data and send by Email

- The power consumption displayed is just an estimate as it is calculated simply.
 It may sometimes differ from the result measured by the power meter.

**In case of have some problem can check from Help menu.**

Google Assistant

**Link account setup and add devices (ACs)**

① Click on + mark

② Select Set up device.

③ Select Works with Google

④ Search Toshiba Home AC Control

⑤ Input Username and Password

⑥ Link account finished, show device

Google Assistant command

| Command Categorize	English Language
	Example command device name is [Bed room]
Power control (ON/OFF)	OK Google, turn on the [Bed room].
	OK Google, turn off the [Bed room].
Mode setting	OK Google, set the [Bed room] to Cool mode.
	OK Google, set the [Bed room] to Heat mode.
	OK Google, set the [Bed room] to Dry mode.
	OK Google, set the [Bed room] to Auto mode.
	OK Google, set the [Bed room] to Fan mode.
Temperature setting	OK Google, set the [Bed room] temperature to 22 degrees.
	OK Google, increase the [Bed room] temperature by 1 degrees.
	OK Google, decrease the [Bed room] temperature by 2 degrees.
Fan speed setting (Recommend to use English language)	OK Google, set the [Bed room] fan speed to Auto.
	OK Google, set the [Bed room] fan speed to Low.
	OK Google, set the [Bed room] fan speed to Low plus.
	OK Google, set the [Bed room] fan speed to Medium.
	OK Google, set the [Bed room] fan speed to Medium plus.
	OK Google, set the [Bed room] fan speed to High.
	OK Google, set the [Bed room] fan speed to Quiet.
	OK Google, increase the [Bed room] fan speed.
	OK Google, decrease the [Bed room] fan speed.
Status inquiry	OK Google, what is the [Bed room] set to ?
	OK Google, what is the temperature in the [Bed room] ?

Amazon Alexa

**Link account setup and add devices (ACs)**

① Select More

② Select Skills & Games

③ Search "Toshiba Home AC Control"

④ Click ENABLE TO USE

⑤ Input Username and Password

⑥ Link account finished

⑦ Discover devices

⑧ Devices found

⑨ Devices list show for set up

⑩ Set up device

⑪ Choose GROUP for your device

⑫ Select continue

⑬ Set up finish

⑭ Check about device list

Command Categorize	English Language		Note
	Example command device name is [Bed room]		Note
Power control (ON/OFF)	Alexa, turn on the [Bed room].		
	Alexa, turn off the [Bed room].		
Mode setting	**Cool mode** : Alexa, set the [Bed room] to Cool mode.		
	Heat mode : Alexa, set the [Bed room] to Heat mode.		
	Dry mode : Not support		Dry mode not support
	Auto mode : Alexa, set the [Bed room] to Auto mode.		
	Fan only mode : Not support.		Fan only mode not support
Temperature setting	Alexa, set the [Bed room] temperature to 22 degrees.		Need to set measurement unit to Celsius (°C) (Both smart speaker and UI)
	Alexa, increase the [Bed room] temperature by 1 degrees.		
	Alexa, decrease the [Bed room] temperature by 2 degrees.		
Fan speed setting (Recommend to use English language)	Alexa, set the [Bed room] fan speed to Low / set the [Bed room] fan speed to 1		
	Alexa, set the [Bed room] fan speed to Low plus / set the [Bed room] fan speed to 2		
	Alexa, set the [Bed room] fan speed to Medium / set the [Bed room] fan speed to 3		
	Alexa, set the [Bed room] fan speed to Medium plus / set the [Bed room] fan speed to 4		
	Alexa, set the [Bed room] fan speed to High / set the [Bed room] fan speed to 5		
	Alexa, set the [Bed room] fan speed to 6		speed 6 = speed Auto
	Alexa, set the [Bed room] fan speed to Quiet / Alexa, set the [Bed room] fan speed to 7		
	Alexa, increase the [Bed room] fan speed. **<= No support this command**		
	Alexa, decrease the [Bed room] fan speed. **<= No support this command**		
Status inquiry	Alexa, what is the [Bed room] set to ?		
	Alexa, what is the temperature in the [Bed room] ?		

Note :

"The Wireless Adapter must be installed, maintained, repaired and removed by a qualified installer or qualified service person."

"Contact dealer and/or service center when equipment is malfunction."